




**20V** Li-ION  
**FASTPOWER**



FDUZ 79200

---

1



2



# Fast Charger **20V** FASTPOWER

## USER'S MANUAL

**Thank you for purchasing this Fast Charger. Before you start using it, please carefully read this user's manual and save it for possible future use.**

## TABLE OF CONTENTS

1. INTENDED USE .....	5
2. GENERAL SAFETY INSTRUCTIONS .....	5
3. BATTERY TOOL USE AND CARE .....	5
4. SYMBOLS AND PICTOGRAMS .....	7
5. CHARGING THE BATTERY PACK.....	8
6. DISPOSAL.....	9
7. TECHNICAL DATA .....	10
8. DECLARATION OF CONFORMITY .....	11

# 1. INTENDED USE

This product is not intended for commercial use. Generally acknowledged accident prevention regulations and enclosed safety instructions must be observed.

Only perform work described in these instructions for use. Any other use is improper. The manufacturer will not assume responsibility for damage resulting from such use.

# 2. GENERAL SAFETY INSTRUCTIONS

- ✿ To operate this device safely, the user must have read and understood these instructions for use before using the device for the first time.
- ✿ Observe all safety instructions! Failure to do so may cause harm to you and others.
- ✿ Retain all instructions for use, and safety instructions for future reference.
- ✿ If you sell or pass the device on, you must also hand over these operating instructions.

# 3. BATTERY TOOL USE AND CARE

- ✿ Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- ✿ Use power tools only with specifically designated battery packs. Use of any other battery packs may create a risk of injury and fire.
- ✿ When battery pack is not in use, keep it away from other metal objects, like paper clips, coins, keys, nails, screws or other small metal objects, that can make a connection from one terminal to another. Shorting the battery terminals together may cause burns or a fire.
- ✿ Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.

## **Additional safety notes**

- ✿ Do not open the battery. The battery may be damaged as a result of improper actions.
- ✿ Do not expose the battery to heat, fire, water and damp. There is a risk of explosion.
- ✿ In the event of damage or incorrect use of the battery, vapours may escape. Make sure that the ventilation is good and, if you have any medical complaints, consult a doctor. These vapours may irritate the air passages and cause illness.
- ✿ Never attempt to recharge batteries that are not designated rechargeable. There is a risk of fire and explosion.
- ✿ The battery may only be used in conjunction with this power tool. Other power tools may overload the battery and thus damage it.
- ✿ Only batteries authorised by the manufacturer with the values listed on the type plate of this power tool may be used. The use of a different battery may cause a risk of injuries and property damage as a result of an exploding battery.

- ✿ Only chargers authorised by the manufacturer with the values listed on the type plate of this battery may be used. The use of a different charger may cause a risk of injuries and property damage as a result of an exploding battery.
- ✿ Symbols affixed to your unit may not be removed or covered. Information on the unit that is no longer legible must be replaced immediately.

## 4. SYMBOLS AND PICTOGRAMS



Before putting the unit into operation, read and observe the instructions for use.



Only re-charge the battery pack indoors.




Do not dispose of a battery pack with the household waste!



Do not dispose of a battery pack in water!



Do not burn the battery pack!



Do not expose the battery pack to sunlight or increased temperatures!

## 5. CHARGING THE BATTERY PACK



**Note:** The rechargeable battery is not included and is available as an option.



**Note:** The actual appearance of your product may differ from the illustrations.

### **⚠ WARNING!**

**Risk of injury! Comply with all safety instructions when handling rechargeable devices.**

### **⚠ NOTICE!**

**Risk of damage to the unit! Do not allow the battery pack to deep discharge.**



**Note:** If the battery is fully loaded, the charger automatically switches over to the maintenance charge function. The battery can thus remain in the charger permanently.

- ✿ The battery pack must be charged prior to the first start-up.
- Press in the locking button (3) and remove the battery from the device.
- Insert the battery pack into the charger.
- Plug the charger into the power supply.

The charging status is displayed by the control lights (4).

- Slot the battery pack into the device and make sure it clicks into place correctly.

### **Control lights (4)**

- ✿ **Green light flashing** - charging
- ✿ **Green light shine** - fully charged battery
- ✿ **Red light flashing** - problem with battery, please carefully check proper insertion of the battery into the charger. If the problem will continue, please contact the nearest service point
- ✿ **Red light shine** - high temperature of battery, please wait at least 60 mins and try again

### **Checking the remaining capacity of the battery**

- Press the button (2).

The remaining capacity of the battery is displayed by the control lights (1).

## 6. DISPOSAL

### INSTRUCTIONS AND INFORMATION ON DISPOSING OF USED PACKAGING MATERIALS

Dispose of used packaging material at a site designated for waste in your municipality.



The appliance and its accessories are manufactured from various materials, e.g. metal and plastic.

Take damaged parts to a recycling centre. Inquire at the relevant government department.

A crossed-out wheeled bin icon means: Batteries and rechargeable batteries, electrical or electronic devices must not be disposed of with household waste. They may contain substances that are harmful to the environment and human health.

Consumers must dispose of waste electrical devices, spent portable batteries and rechargeable batteries separately from household waste at an official collection point to ensure that these items are processed correctly. Information on returning these items is available from the seller. Sellers are required to accept these items free of charge. Batteries and rechargeable batteries, which are not permanently installed in waste electrical devices, must be removed prior to disposal and must be disposed of separately. Lithium batteries and battery packs in all systems must only be returned to a collection point when discharged. Batteries must always be protected against short circuits by covering the poles with adhesive tape.

All end users are responsible for deleting any personal data stored on waste devices prior to their disposal.




This appliance meets all the basic requirements of the EU directives.

Changes in the text, design and technical specifications may be made without prior notice and we reserve the right to make these changes.

User manual in the original language.

## 7. TECHNICAL DATA

Item number	FDUZ 79200 Fast charger
Rated voltage	230 V~, 50 Hz
Rated power	140 W
Charge voltage	20,9 V 
Charge current	2,4 A
Protection class	II
Charging time	2 Ah / 30 min, 4 Ah / 60 min, 8Ah / 120 min

# 8. DECLARATION OF CONFORMITY

# FAST®

FAST ČR, a.s.  
U Sanitasu 1621, 251 01 Říčany, Czech Republic  
tel.: +420 323 204 111, fax: +420 323 204 110

## EU DECLARATION OF CONFORMITY

**Product / brand:** Battery Charger / FIELDMANN

**Type / model:** FDUZ 79200 as factory model D02103100  
Input: AC 200-240V; 50/60 Hz; 140W; Class II  
Output: DC 20,0V; 4,5A

**Manufacturer:** FAST ČR, a.s.  
U Sanitasu 1621, 251 01 Říčany, Czech Republic  
VAT no: CZ2477749

**This declaration of conformity is issued under the sole responsibility of the manufacturer.**

**The object of the declaration described above is in conformity with the relevant Union harmonization legislation:**

Directive LVD 2014/35/EU                      Directive EMC 2014/30/EU  
Directive RoHS 2011/65/EU

**The relevant harmonized standards and the other technical specifications:**

EN 60335-1:2012+A11+A13+A1+A14+A2+A15	EN 60335-2-29:2021+A1
EN 62233:2008	
EN IEC 55014-1:2021	EN IEC 61000-3-2:2019+A1
EN IEC 55014-2:2021	EN 61000-3-3:2013+A1+A2



**Place of issuance:** Prague  
**Date of issuance:** 24. 08. 2023

**Name:** Petr Uher - Responsible Person  
**Signature:**

**FAST** FAST ČR, a.s.  
U Sanitasu 1621, 251 01 Říčany  
tel.: +420 323 204 111  
IČO: 247 77 249, DIČ: CZ 247 77 749

IČO:2477749, DIČ:CZ2477749

Bankovní spojení: Komerční banka Praha 1, č.ú. 89309011/0100, ČSOB Praha 1, č.ú. 8010-0116233383/0300  
Česká spořitelna Praha 4, č.ú. 2375682/0800

